


# Driver Side Temperature Door Actuator

Base Part Number: Base Part Number: 19E616

## Removal

1. Disconnect the electrical connector, remove the retainers and the driver side temperature door actuator.



## Installation

1. To install, reverse the removal procedure.