

Parking Aid - Overview

Parking Aid - Audible

The rear parking aid system sounds a warning tone through the rear audio speakers to alert the driver of objects near the rear bumper when the transmission is in reverse. The rear parking aid system assists the driver in detecting certain objects when the vehicle is stationary or moving slowly in reverse. The rear parking aid system may not detect moving objects.

The parking aid system is disabled if a fault is detected in a parking aid sensor, the communications network or the PAM. This is indicated by a parking aid disabled warning message in the IPC message center.

The parking aid system is enabled and disabled through the message center, located in the IPC. Disabling the parking aid system lasts one key cycle.

If a MyKey® restricted key is in use, the parking aid menu is not available in the message center and cannot be deactivated.