


Telematics Control Unit (TCU) Module Antenna

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Lower the headliner.
Refer to: [Headliner - Lowering - SuperCrew](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
Refer to: [Headliner - Lowering - SuperCab](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
Refer to: [Headliner - Lowering - Regular Cab](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Remove the bolt and the TCU module antenna.
 - Disconnect the electrical connector.
Torque: 49 lb.in (5.5 Nm)



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company
