


SYNC Module [APIM]

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Remove the FDIM.
Refer to: [Front Display Interface Module \(FDIM\)](#) (415-00C Information and Entertainment System - General Information - Vehicles With: Touchscreen Display, Removal and Installation).
2. Remove the screws, disconnect the electrical connector and separate the APIM from the FDIM.



Installation

1. To install, reverse the removal procedure.
2. If a new APIM is being installed, program the APIM to the correct software level.
Refer to: [SYNC Module \[APIM\] Programming](#) (415-00C Information and Entertainment System - General Information - Vehicles With: Touchscreen Display, General Procedures).

Copyright © 2018 Ford Motor Company

mcx30.com