


Stoplamp Switch

Base Part Number: Base Part Number: 9G854

Removal


NOTICE: Do not press or pull on brake pedal when installing or removing the stoplamp switch otherwise misadjustment or damage to the stoplamp switch can occur.

1. Disconnect the stoplamp switch electrical connetor.



2. Rotate the switch 1/4 turn clockwise and remove the stoplamp switch.





Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company
