


Rear Lamp Bulb

Removal

1. Remove the rear lamp assembly.
Refer to: Rear Lamp Assembly (417-01) .
2. Remove the rear lamp bulb holder and remove the rear lamp bulb.



Installation

1. To install, reverse the removal procedure.

mcx30.com