



Front Marker Lamp

Removal

1. Disconnect the front marker lamp electrical connector.



2. Remove the bulb holder and the front marker lamp bulb.



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company