



Auxiliary Switches

Removal

1. Remove the overhead console.
Refer to: [Overhead Console](#) (501-12 Instrument Panel and Console, Removal and Installation).
2. Release the tabs and remove the trim panel.



3. Release the tabs and remove the auxiliary switch panel.



Installation

1. To install, reverse the removal procedure.

Copyright © 2018 Ford Motor Company