

Engine Front Undershield

1. **NOTE:** 4X2 vehicle shown, 4X4 vehicle similar.

Remove the engine front undershield.

1. Remove the bolts.
Torque: 30 lb.ft (40 Nm)
2. Remove the bolts and the engine front undershield.
Torque: 71 lb.in (8 Nm)

