

Diagnostic Trouble Code Charts

Master DTC Index

Module	Section
APIM	REFER to: Information and Entertainment System (415-00 Information and Entertainment System - General Information, Diagnosis and Testing).
ABS module	REFER to: Anti-Lock Brake System (ABS) and Stability Control (206-09 Anti-Lock Brake System (ABS) and Stability Control, Diagnosis and Testing).
ACM	REFER to: Information and Entertainment System (415-00 Information and Entertainment System - General Information, Diagnosis and Testing).
BCM	REFER to: Body Control Module (BCM) (419-10 Multifunction Electronic Modules, Diagnosis and Testing).
CCM	REFER to: Cruise Control (419-03B Cruise Control - Vehicles With: Adaptive Cruise Control, Diagnosis and Testing).
DSP	REFER to: Information and Entertainment System (415-00 Information and Entertainment System - General Information, Diagnosis and Testing).
DDM	REFER to: Locks, Latches and Entry Systems (501-14 Handles, Locks, Latches and Entry Systems, Diagnosis and Testing).
DSM	REFER to: Front Seats (501-10A Front Seats, Diagnosis and Testing).
FCIM	REFER to: Information and Entertainment System (415-00 Information and Entertainment System - General Information, Diagnosis and Testing).
GWM	REFER to: Communications Network (418-00 Module Communications Network, Diagnosis and Testing).
GFM (Trailer TPMS)	REFER to: Tire Pressure Monitoring System (TPMS) (204-04B Tire Pressure Monitoring System (TPMS), Diagnosis and Testing).
GFM2 (Upfitter Switches)	REFER to: Generic Function Module 2 (GFM2) (419-10 Multifunction Electronic Modules, Diagnosis and Testing).
HUD module	REFER to: Collision Warning and Collision Avoidance System (419-03C Collision Warning and Collision Avoidance System, Diagnosis and Testing).
HSWM	REFER to: Steering Wheel and Column Electrical Components (211-05 Steering Wheel and Column Electrical Components, Diagnosis and Testing).
IPC	REFER to: Instrumentation, Message Center and Warning Chimes (413-01 Instrumentation, Message Center and Warning Chimes, Diagnosis and Testing).
IPMA	REFER to: Lane Keeping System (419-07 Lane Keeping System, Diagnosis and Testing).
IPMB	REFER to: Parking Aid (413-13B Parking Aid - Vehicles With: Parking Aid Camera, Diagnosis and Testing).
PAM	REFER to: Parking Aid (413-13A Parking Aid, Diagnosis and Testing).

Module	Section
PCM	- For 6.2L, REFER to: Electronic Engine Controls (303-14A Electronic Engine Controls - 6.2L V8, Diagnosis and Testing). - For 7.3L, REFER to: Electronic Engine Controls (303-14C Electronic Engine Controls - 7.3L 2V DEVCT V8 (239kW/320PS) (J0), Diagnosis and Testing). - For 6.7L Diesel, REFER to: Electronic Engine Controls (303-14B Electronic Engine Controls - 6.7L Power Stroke Diesel, Diagnosis and Testing).
PDM	REFER to: Locks, Latches and Entry Systems (501-14 Handles, Locks, Latches and Entry Systems, Diagnosis and Testing).
PSCM	- Without electronic steering actuator, REFER to: Power Steering (211-02 Power Steering, Diagnosis and Testing). - With electronic steering actuator, REFER to: Power Steering - Vehicles With: Electronic Steering Actuator (211-02 Power Steering, Diagnosis and Testing).
RTM	REFER to: Tire Pressure Monitoring System (TPMS) (204-04B Tire Pressure Monitoring System (TPMS), Diagnosis and Testing).
RCM	REFER to: Airbag Supplemental Restraint System (SRS) (501-20B Supplemental Restraint System, Diagnosis and Testing).
RBM	REFER to: Power Running Board (PRB) (501-08 Exterior Trim and Ornamentation, Diagnosis and Testing).
SCME	REFER to: Front Seats (501-10A Front Seats, Diagnosis and Testing).
SCMG	REFER to: Front Seats (501-10A Front Seats, Diagnosis and Testing).
SCMH	REFER to: Front Seats (501-10A Front Seats, Diagnosis and Testing).
SASM	REFER to: Anti-Lock Brake System (ABS) and Stability Control (206-09 Anti-Lock Brake System (ABS) and Stability Control, Diagnosis and Testing).
SECM	REFER to: Adaptive Steering (211-02 Power Steering, Diagnosis and Testing).
SCCM	REFER to: Steering Wheel and Column Electrical Components (211-05 Steering Wheel and Column Electrical Components, Diagnosis and Testing).
SODL	REFER to: Blind Spot Information System (419-04 Side and Rear Vision, Diagnosis and Testing).
SODR	REFER to: Blind Spot Information System (419-04 Side and Rear Vision, Diagnosis and Testing).
TBM	REFER to: Auxiliary Brake System - Vehicles With: Trailer Brake Control (206-10 Auxiliary Brake System, Diagnosis and Testing).
TRM	REFER to: Trailer Lamps (417-01 Exterior Lighting, Diagnosis and Testing).
TCM	REFER to: Diagnostic Trouble Code (DTC) Charts and Pinpoint Tests - 6.7L Power Stroke Diesel (307-01B Automatic Transmission, Transfer Case and Power Transfer Unit - 10-Speed Automatic Transmission & 10R140, Diagnosis and Testing).
TCCM	REFER to: Four-Wheel Drive Systems - Electronic Shift (308-07A Four-Wheel Drive Systems, Diagnosis and Testing).
TCU	REFER to: Information and Entertainment System (415-00 Information and Entertainment System - General Information, Diagnosis and Testing).
WACM	REFER to: Wireless Accessory Charging Module (WACM) (414-06 Accessory Charging, Diagnosis and Testing).

