



Climate Control System - Vehicles With: Dual Automatic Temperature Control (DATC) - Component Location




Item	Description
1	In-Vehicle Temperature & Humidity Sensor
2	Auto Lamp Sensor
3	FCIM & HVAC Module



Item	Description
1	Air Distribution Door Actuator
2	Driver Side Register Air Discharge Temperature Sensor
3	Passenger Side Register Air Discharge Temperature Sensor
4	Passenger Side Temperature Door Actuator

5	Air Inlet Door Actuator
6	Cabin Air Filter
7	Blower Motor Control Module
8	Evaporator
9	Evaporator Temperature Sensor
10	Driver Side Temperature Door Actuator
11	Heater Core
12	Passenger Side Footwell Air Discharge Temperature Sensor
13	Driver Side Footwell Air Discharge Temperature Sensor

6.2L shown, all other engines similar



Item	Description
1	A/C Compressor
2	Evaporator Inlet & Outlet Manifold
3	Thermostatic Expansion Valve
4	Climate Control Housing
5	Ambient Air Temperature Sensor
6	A/C Compressor Inlet Line
7	A/C Pressure Transducer
8	A/C Compressor Outlet Line
9	Condenser
10	Desiccant Bag

