



Climate Control System - Vehicles With: Electronic Manual Temperature Control (EMTC) - Component Location




Item	Description
1	In-Vehicle Temperature & Humidity Sensor
2	Auto Lamp & Sunload Sensor
3	FCIM & HVAC Module



Item	Description
1	Air Distribution Door Actuator
2	Air Inlet Door Actuator
3	Cabin Air Filter
4	Blower Motor Control Module

5	Evaporator
6	Evaporator Temperature Sensor
7	Driver Side Temperature Door Actuator
8	Heater Core
9	Driver Side Footwell Air Discharge Temperature Sensor

6.2L shown, all other engines similar



Item	Description
1	A/C Compressor
2	Evaporator Inlet & Outlet Manifold
3	Thermostatic Expansion Valve
4	Climate Control Housing
5	Ambient Air Temperature Sensor
6	A/C Compressor Inlet Line
7	A/C Pressure Transducer
8	A/C Compressor Outlet Line
9	Condenser
10	Desiccant Bag

