

Supplemental Climate Control - Overview

Overview

An electric booster heater is available as optional equipment on diesel vehicles. The climate control system uses the electric booster heater to heat the passenger compartment in place of the heater core in low ambient temperatures. Once engine coolant reaches a sufficient temperature to heat the passenger compartment, the climate control system stops using the electric booster heater.

mcx30.com