


## Electric Booster Heater

### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

1. Remove the instrument panel.  
Refer to: Instrument Panel (501-12 Instrument Panel and Console, Removal and Installation).
2.
  1. Disconnect the electrical connector.
  2. Remove the retainers and the electric booster heater.



### Installation

1. To install, reverse the removal procedure.