

# Battery and Cables - System Operation and Component Description

## System Operation

### Battery and Cables

The battery is a 12V DC source connected in a negative ground system and is a voltage stabilizer for the 12V electrical system.

## Component Description

### Battery

Vehicles are equipped with a 12-volt, maintenance-free battery/batteries.

Dual batteries are standard on the 6.7L diesel engine vehicles and optional on other vehicles.

Ford Motor Company strongly recommends that all faulty lead-acid batteries be returned to an authorized recycling facility for disposal.

---