

Power Mirrors Synchronization

Synchronization

NOTE: The power folding mirrors may need to be synchronized any time the mirrors are folded or unfolded without using the folding switch, or if a new power folding mirror is installed.

NOTE: The power telescoping mirrors may need to be synchronized any time the mirrors are extended or retracted without using the telescoping switch, or if a new power telescoping mirror is installed.

NOTE: If the power folding or power telescoping mirrors are continuously electronically moved, the power lockout feature disables the system for approximately 3-10 minutes to prevent damage to the power fold or power telescope motors. After 3-10 minutes have elapsed, normal operation resumes.

NOTE: The truck power folding mirror procedure is shown in the videos; other vehicles and power telescoping mirror procedure are similar.

1. Fold or retract both mirrors by hand.
2. Using the power folding/power telescoping mirror switch, operate the mirrors until an audible click is heard.
3. Operate the power folding or power telescoping mirrors an additional 3 to 4 times to synchronize the mirrors.
4. For vehicles equipped with the mirror control switch integral to the window switch, refer to the video below.

[Click here to view a video version of this procedure.](#)

5. For vehicles equipped with the stand alone mirror control switch, refer to the video below.

[Click here to view a video version of this procedure.](#)
