


Rear Door Window Control Switch - Super Cab, Vehicles With: Rear Power Windows

Removal

NOTE: NOTE: LH side shown, RH side similar.

1. Remove the rear door trim panel.
Refer to: Rear Door Trim Panel - Super Cab (501-05 Interior Trim and Ornamentation, Removal and Installation).
2. Remove the rear door window control switch.
 1. Release the locking tabs from the rear door window control switch.
 2. Remove the rear door window control switch.



Installation

1. To install, reverse the removal procedure.