


Overhead Console

Special Tool(s) / General Equipment

Interior Trim Remover

Removal

1. Working from the rear forward, release the clips and remove the overhead console.
 - Disconnect the electrical connectors.Use the General Equipment: Interior Trim Remover



Installation

1. To install, reverse the removal procedure.