


Keyless Entry Keypad

Removal

1. Remove the front door upper moulding.
Refer to: Front Door Upper Moulding (501-08 Exterior Trim and Ornamentation, Removal and Installation).
2. Remove the keyless entry keypad.
 1. Release the retaining tabs on the keyless entry keypad.
 2. Remove the keyless entry keypad from the front door upper moulding.



Installation

1. To install, reverse the removal procedure.