


Wipers and Washers - Overview

Overview



The windshield wiper/washer system is activated by the wiper/washer switch. The following functions/features of the windshield wiper/washer system are:

- Windshield wash (includes camera wash, if equipped)
- Courtesy wipe
- Windshield wipers (low/high speed)
- Intermittent wipers
- Speed dependent wipers
- Wiper activated exterior lamps
- Rain sensitive wipers (if equipped)

There are 5 intermittent/sensitivity settings to choose from for the intermittent/rain sensitive wipers.

Heated Wiper Park Overview

The HVAC controls the rear window defrost relay, which is located in the BJB. When the rear window defrost button on the FCIM is pressed, the HVAC activates the rear window defrost relay. When the rear window defrost relay is active, it provides power to the rear window defrost grid, and to the coil side of the heated wiper park relay, which supplies power to the heated wiper park grid.

