



Windshield Washer Jets

Removal

1. Remove the cowl panel grill.
Refer to: Cowl Panel Grille (501-02 Front End Body Panels, Removal and Installation).
2. Disconnect the windshield washer hose(s).



3. Press inward on the tabs and remove the windshield washer jet(s).



Installation

1. To install, reverse the removal procedure.