

Clear The Continuous Diagnostic Trouble Codes (DTCs) And Reset The Emission Monitors Information In The Powertrain Control Module (PCM)**Description**

All on board diagnostic (OBD) scan tools support the clearing of continuous DTCs and resetting of emission monitors information in the PCM.

The clearing of the continuous DTCs allows the scan tool to command the PCM to clear and reset all emission related diagnostic information.

The following events occur when the continuous DTCs and the emission monitors information is cleared from the PCM:

- the number of DTCs is reset
 - the DTCs are cleared (on vehicles with permanent DTCs, additional vehicle operation is required to complete and pass the appropriate monitors to complete the clearing of permanent DTCs)
 - the freeze frame data is cleared
 - the diagnostic monitoring test results are reset
 - the status of the OBD system monitors is reset
-