

No Diagnostic Trouble Codes (DTCs) Present Symptom Chart Index

System/Symptom		Oasis Number	Chart Number
Driveability			
Starting Concerns	No Crank/Slow Crank	-	1
	Hard Start/Long Crank/Erratic Start/Erratic Crank	-	3
	Stall After Start	-	3
	No Start/Normal Crank	-	3
Unique Idle Concerns	Slow Return To Idle	-	4
	Rolling Idle	-	5
	Fast Idle	-	4
Driveability — Performance While Driving Concerns			
Stalls/Quits	Idle	-	2
	Acceleration	-	2
	Cruise	-	2
	Deceleration	-	2
Runs Rough	Idle	-	5
	Acceleration	-	6
	Cruise	-	6
Misses	Idle	-	6
	Acceleration	-	6
	Cruise	-	6
Buck/Jerk	Acceleration	-	6
	Cruise	-	6
	Deceleration	-	6
Hesitation/Stumble		-	6
Surge	Acceleration	-	6
	Cruise	-	6
Lack/Loss of Power	Acceleration	-	6
	Cruise	-	6
Additional Driveability Concerns			
Poor Fuel Economy		-	6
Extended Idle Shutdown		-	14
Regeneration Concerns		-	15
Electrical			
Warning Indicators	Malfunction Indicator Lamp (MIL)	-	7