


Powertrain Secondary Cooling - Component Location

NOTE: Coolant temperature will vary with ambient temperature and load. Temperatures shown are for ambient temperature of 38°C (100°F). Red arrows indicate a temperature over 45°C (113°F), Orange arrows indicate a temperature of approximately 45°C (113°F), Blue arrows indicate a temperature below 45°C (113°F).



Item	Description
1	Radiator
2	Thermostat
3	Coolant crossover hose assembly
4	Coolant pump-to-radiator supply hose
5	Coolant pump
6	Degas bottle-to-coolant pump hose
7	Degas bottle-to-radiator hose
8	Degas bottle
9	Pressure relief cap
10	CAC outlet hose
11	CAC
12	CAC inlet hose
13	Fuel cooler
14	Fuel cooler inlet hose

