



Fuel Charging and Controls - Component Location

6.2L V8




Item	Description
1	Throttle Body (TB)
2	Fuel injectors
3	Fuel rails

Pickup - FPDM (fuel pump driver module)



Item	Description
1	FPDM (fuel pump driver module) Comments: The fuel pump driver module (FPDM) is attached to the top of the frame rear crossmember.

Chassis Cab - FPDM (fuel pump driver module)



Item	Description
1	FPDM (fuel pump driver module) Comments: The fuel pump driver module (FPDM) is attached to the front of the frame rear crossmember.