


Evaporative Emissions - System Operation and Component Description

System Operation

Refer to the PC/ED manual section 1 Description and Operation.

System Diagram



Item	Description
1	Intake manifold
2	EVAP purge valve
2	Fresh air vent tube
4	EVAP canister inlet filter
5	EVAP canister vent valve
6	EVAP canister
7	Fuel tank
8	Fuel vapor vent valve
9	Fuel level sensor (FLS)
10	Fuel delivery module (FDM)
11	Fuel tank filler pipe
12	Fuel tank pressure sensor
13	Evaporative VBV (only on ORVR (on-board refueling vapour recovery) tanks).

