

Removal and Installation

General Equipment

Ford Diagnostic Equipment

Removal


1. **NOTE:** This step is only necessary when installing a new component.

Download the module information to the diagnostic tool using the Programmable Modules Installation routine.


Use the General Equipment: [Ford Diagnostic Equipment](#)

2. Refer to: [Battery Disconnect and Connect](#) (414-01 Battery, Mounting and Cables, General Procedures).

- 3.



4. Torque: 10 Nm



Installation

1. To install, reverse the removal procedure.

2. **NOTE:** This step is only necessary when installing a new component.

Upload the module information from the diagnostic tool to the module using the Programmable Modules Installation routine.