

Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.



 **WARNING:** Do not smoke, carry lighted tobacco or have an open flame of any type when working on or near any fuel-related component. Highly flammable mixtures may be present and may be ignited. Failure to follow these instructions may result in serious personal injury.

Refer to: [Gasoline and Gasoline-Ethanol Fuel Systems Health and Safety Precautions](#) (100-00 General Information, Description and Operation).

1.5L EcoBoost (118kW/160PS)

2. Remove the following items:

- Refer to: [Fuel Pump and Sender Unit](#) (310-01B Fuel Tank and Lines, Removal and Installation).

All vehicles

3.



Installation

1. To install, reverse the removal procedure.