

Removal and Installation

Removal


NOTE: Removal steps in this procedure may contain installation details.

1.  **WARNING:** Before beginning any service procedure in this section, refer to Safety Warnings in section 100-00 General Information. Failure to follow this instruction may result in serious personal injury.

Refer to: [Climate Control System Health and Safety Precautions](#) (100-00 General Information, Description and Operation).

2. Refer to: [Steering Column](#) (211-04 Steering Column, Removal and Installation).

- 3.



Installation

1. To install, reverse the removal procedure.