



Removal and Installation

Removal

1. Left-hand side only.




2. Left-hand side only.




3. Left-hand side only.




4. Left-hand side only.




5. Right-hand side only.




6. Right-hand side only.




7. Right-hand side only.



8. Right-hand side only.




9. Right-hand side only.



10. Right-hand side only.




11. Right-hand side only.



NOTE: This step is only necessary when installing a new component.
NOTE: Left hand drive (LHD) shown, right hand drive (RHD) similar.

12.



Installation

1. To install, reverse the removal procedure.

2. Refer to: [Front Fog Lamp Adjustment](#) (417-01 Exterior Lighting, General Procedures).

mcx30.com