


Removal and Installation

Removal


NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Front Bumper Cover](#) (501-19 Bumpers, Removal and Installation).
Refer to: [Active Grille Shutter](#) (501-02 Front End Body Panels, Removal and Installation).


2.



3. Torque: 27 Nm



4. Torque: 9 Nm



Installation

1.
 - To install, reverse the removal procedure.
 - Refer to: [Cruise Control Radar Alignment](#) (419-03A Cruise Control, General Procedures).