

Removal and Installation


Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Front Bumper Cover](#) (501-19 Bumpers, Removal and Installation).

All vehicles


2.




3. Torque: 6 Nm



4.



5. On both sides.



6. Torque: 6 Nm



Installation

1. To install, reverse the removal procedure.