

General Procedures

General Equipment

Ford Diagnostic Equipment

Initialization

1. Connect the diagnostic scan tool.

Use the General Equipment: [Ford Diagnostic Equipment](#)

2. Make sure that the liftgate is closed.

3. Turn the Ignition ON.

4. **NOTE: Make sure that the component moves freely between the end positions.**

From the diagnostic scan tool, enter TOOLBOX. Select Selftest/Modules/RGTM and carry out the self-test routine. After passing the self-test without errors, the power liftgate has been initialized.

mcx30.com