


Removal and Installation

Removal


NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Liftgate Trim Panel - 5-Door](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


2.




3.



4.



5. On both sides.



6. Torque: 50 Nm



Installation

1. To install, reverse the removal procedure.

mcx30.com