

Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. **NOTE:** Removal steps in this procedure may contain installation details.

2. On both sides.

Refer to: [A-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


Refer to: [B-Pillar Trim Panel](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).

Refer to: [D-Pillar Trim Panel - 5-Door](#) (501-05 Interior Trim and Ornamentation, Removal and Installation).


3.




4. If equipped.




5. If equipped.




6. If equipped.




7. If equipped.



8.




9. On both sides.




10. On both sides.




11. Remove all handles.




12.




13.




14. If equipped.



15. If equipped.




16. If equipped.




17. If equipped.



18.




19.




20.



21. **NOTE:** This step is only necessary when installing a new component.
On both sides.



22. **NOTE:** This step is only necessary when installing a new component.
On both sides.



Installation

1. To install, reverse the removal procedure.

mcx30.com