

## Supplemental Restraint System - Passenger Airbag Deactivation (PAD) Indicator




### Removal and Installation


#### Removal

NOTE: Removal steps in this procedure may contain installation details.

1.



2.



#### Installation

1. To install, reverse the removal procedure.