

DIAGNOSIS AND TESTING > INSTRUMENTATION, MESSAGE CENTER AND WARNING CHIMES > PINPOINT TESTS > PINPOINT TEST BL : THE TURN SIGNAL-HAZARD ON CHIME OR TURN SIGNAL LEFT ON CHIME IS INOPERATIVE

Normal Operation and Fault Conditions

See Turn Signal On Chime Tone. REFER to: Warning Chimes - System Operation and Component Description .

Possible Sources

- Turn signal indication concern
- Communication concern
- BCM concern
- GWM concern
- IPC

DIAGNOSIS AND TESTING > INSTRUMENTATION, MESSAGE CENTER AND WARNING CHIMES > PINPOINT TESTS > PINPOINT TEST BL : THE TURN SIGNAL-HAZARD ON CHIME OR TURN SIGNAL LEFT ON CHIME IS INOPERATIVE > PINPOINT TEST BL : THE TURN SIGNAL-HAZARD ON CHIME OR TURN SIGNAL LEFT ON CHIME IS INOPERATIVE

BL1 CHECK THE SAFETY BELT WARNING CHIME OPERATION

Ignition OFF.

Ignition ON.

Unbuckle the driver safety belt.

Monitor the safety belt warning chime when the ignition is transitioned from OFF to RUN for 6 seconds.

Does the safety belt warning chime operate for approximately 6 seconds?

Yes	GO to BL2
No	INSTALL a new IPC. REFER to: Instrument Panel Cluster (IPC) .

BL2 CHECK THE TURN SIGNAL INDICATOR OPERATION

Verify the RH and LH turn signal indicators operate correctly.