




Fuel Injector

Horn

Switch - Backup Lamp

Switch - Hood Ajar

## CONNECTOR VIEWS > CONNECTOR END VIEW C183 - FUEL INJECTOR 3

**Connector:**C183

**Description**

FUEL INJECTOR 3

**Color**

GY

**Harness**


12C508

**Base Part #**

part# N/A

**Service Pigtail**

See Below



Check for Terminal Part Numbers

| Pin | Circuit       | Gauge | Circuit Function                                        | Qualifier |
|-----|---------------|-------|---------------------------------------------------------|-----------|
| 1   | CE207 (VT-GY) | 20    | CTRL MOD. - POWERTRAIN # FUEL INJECTOR DRIVER 3 (INJ) + |           |
| 2   | CBK01 (BU)    | 20    | FUSE - 41 OR CIRCUIT BREAKER (VPWR F)                   |           |

Available Pigtail Kits

Pigtail Kit Part Number

**WPT-1051**

Service Part Number:

**5U2Z-14S411-ZB**

Gauge:

**16**

Pin material:

**Silver**

Cavities:

**2**