



REMOVAL AND INSTALLATION > BRAKE CALIPER ANCHOR PLATE > INSTALLATION

1.

To install, reverse the removal procedure.

REMOVAL AND INSTALLATION > BRAKE DISC

Materials

Name	Specification
Metal Brake Parts Cleaner (U.S.) PM-4-A, PM-4-B (U.S.)	-

REMOVAL AND INSTALLATION > BRAKE DISC > REMOVAL



NOTE: Do not allow the brake caliper to hang from the brake hose or damage to the brake hose may occur.



NOTE: Removal steps in this procedure may contain installation details.

All brake calipers

1.

Remove the wheel and Tire. Refer to: Wheel and Tire .

2-piston brake caliper

2.