





141.

Inspect the cylinder block distortion. Refer to: Cylinder Block Distortion .

DISASSEMBLY AND ASSEMBLY OF SUBASSEMBLIES > CYLINDER HEAD

Special Tool(s) / General Equipment

 E223048	303-1249 Valve Spring Compressor TKIT-2006UF-FLM TKIT-2006UF-ROW
 E134677	303-300 (T87C-6565-A) Set, Valve Spring Compressor T88C-1000-ST TKIT-1988-FESTIVA TKIT-1988-TRACER TKIT-2009TC-F
 E134678	303-350 (T89P-6565-A) Compressor, Valve Spring TKIT-1989-F TKIT-1989-FLM TKIT-1989-FM TKIT-1990-LMH