

GENERAL PROCEDURES > POWERTRAIN DRIVETRAIN MOUNT NEUTRALIZING

Adjustment



NOTE: Refer to the appropriate article and procedure for special instructions on loosening and tightening mount fasteners.

1.

Loosen, but do not remove, the powertrain/drivetrain mount fasteners.



NOTE: Do not twist or strain the powertrain/drivetrain mounts or damage to the mounts may occur.

2.

Start the vehicle and move it in forward 0.6 m (1.97 ft) - 1.2 m (3.94 ft). Then move the vehicle in reverse the same distance.

3.

Tighten the powertrain/drivetrain mount fasteners.

4.

Test the system for normal operation.

GENERAL PROCEDURES > RTV SEALING SURFACE CLEANING AND PREPARATION

Special Tool(s) / General Equipment

Plastic Scraper

Materials

Name	Specification
Motorcraft ® Silicone Gasket Remover ZC-30-A	-
Motorcraft ® Metal Surface Prep ZC-31-B	-
Metal Brake Parts Cleaner (U.S.) PM-4-A, PM-4-B (U.S.)	-

Cleaning



NOTE: Place clean, lint-free towels over exposed cavities. Carefully remove the towels