

REMOVAL AND INSTALLATION > BRAKE BOOSTER - 3.7L DURATEC (227KW 301PS) > INSTALLATION

 **NOTE:** Do not press, pull or otherwise move the brake pedal while installing the stoplamp switch. The switch must be installed with the booster push rod attached to the brake pedal and with the brake pedal in the at-rest position. Installing the switch with the brake pedal in any other position will result in incorrect adjustment and may damage the switch.

1.
To install, reverse the removal procedure.

2.

Bleed the brake system. Refer to: Brake System Pressure Bleeding .

REMOVAL AND INSTALLATION > BRAKE BOOSTER - 5.0L 32V TI-VCT > REMOVAL

 **NOTE:** If the fluid is spilled on the paintwork, the affected area must be immediately washed down with cold water.

 **NOTE:** Removal steps in this procedure may contain installation details.

All vehicles

1.

Remove the cowl panel grill. Refer to: Cowl Panel Grille .

2.

Disconnect the battery cables. Refer to: Battery Disconnect and Connect .

3.

Detach the vacuum check valve from the booster and position aside.