



REMOVAL AND INSTALLATION > BRAKE CALIPER > INSTALLATION

1.

To install, reverse the removal procedure.

2.

Bleed the brake system. Refer to: Brake System Pressure Bleeding .

3.

Adjust park brake system. Refer to: Parking Brake Cable Adjustment .

REMOVAL AND INSTALLATION > BRAKE CALIPER ANCHOR PLATE > REMOVAL



NOTE: Removal steps in this procedure may contain installation details.

1.

Remove the brake pads. Refer to: Brake Pads .



NOTE: Do not allow the brake caliper and anchor plate assembly to hang from the brake hose or damage to the hose may occur.

2.

Remove the 2 bolts and the brake caliper anchor plate. Discard the bolts.

Torque

: 129 lb.ft (175 Nm)