

- Camshaft advance mechanism binding (VCT unit)

Diagnostic Aids: This DTC is a functional check of the VCT unit. Diagnose any base engine concerns related to the engine oil pressure or engine timing. Refer to the service information , Engine System, Oil Pressure Test, to check the engine oil pressure. Refer to the service information , Engine, Timing Drive Components, to check the engine timing.

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test HK .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P0562 - SYSTEM VOLTAGE LOW - DTC CHART

P0562 - SYSTEM VOLTAGE LOW - DTC CHART

Description:			
Possible Causes:			
Diagnostic Aids: Refer to the service information , Electronic Engine Controls.			
Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	Refer to the Description, Possible Causes and Diagnostic Aids for the DTC.		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P0563 - SYSTEM VOLTAGE HIGH - DTC CHART

P0563 - SYSTEM VOLTAGE HIGH - DTC CHART

Description:			
Possible Causes:			
Diagnostic Aids: Refer to the service information , Electronic Engine Controls.			
Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	Refer to the Description, Possible Causes and Diagnostic Aids for the DTC.		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P0571 - BRAKE SWITCH A CIRCUIT - DTC CHART

P0571 - BRAKE SWITCH A CIRCUIT - DTC CHART

Description: This DTC sets when the brake switch does not toggle during the key ON engine running