

SERIAL COMMUNICATION LINK - DTC CHART

P0600 - SERIAL COMMUNICATION LINK - DTC CHART

Description: This DTC sets when an error occurs in the PCM. This DTC may set alone or with P2105.

Possible Causes:

- Software incompatibility issue
- Damaged PCM

Diagnostic Aids:

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test QE .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P0602 - POWERTRAIN CONTROL MODULE PROGRAMMING ERROR - DTC CHART

P0602 - POWERTRAIN CONTROL MODULE PROGRAMMING ERROR - DTC CHART

Description: This DTC sets when there is a programming error within the vehicle identification (VID) block.

Possible Causes:

- VID data corrupted by the scan tool during VID reprogramming

Diagnostic Aids: Program the VID block. Refer to FLASH ELECTRICALLY ERASABLE PROGRAMMABLE READ ONLY MEMORY (EEPROM) , Making Changes to the VID Block. If the PCM does not allow reprogramming of the VID block, reflashing of the PCM is required.

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	Refer to the Description, Possible Causes and Diagnostic Aids for the DTC.		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P0603 - INTERNAL CONTROL MODULE KEEP ALIVE MEMORY (KAM) ERROR - DTC CHART

P0603 - INTERNAL CONTROL MODULE KEEP ALIVE MEMORY (KAM) ERROR - DTC CHART

Description: This DTC sets when the PCM has experienced an internal memory concern. However, there are external items that can cause this DTC.

Possible Causes:

- Reprogramming