

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P062F - INTERNAL CONTROL MODULE EEPROM ERROR - DTC CHART

P062F - INTERNAL CONTROL MODULE EEPROM ERROR - DTC CHART

Description: The PCM read only memory (ROM) has been corrupted.

Possible Causes:

- Aftermarket performance products
- An attempt was made to change the calibration
- PCM programming error
- PCM internal software error
- Damaged PCM

Diagnostic Aids: Reprogram or update the calibration. Check for other DTCs or drive symptoms for further action. Check for aftermarket performance products before installing a new PCM. If it is necessary to install a new PCM, refer to FLASH ELECTRICALLY ERASABLE PROGRAMMABLE READ ONLY MEMORY (EEPROM) , Programming the VID Block for a Replacement PCM.

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	Refer to the Description, Possible Causes and Diagnostic Aids for the DTC.		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P062X - DTC CHART

P062X - DTC CHART

Description:

Possible Causes:

Diagnostic Aids: Refer to the service information , Electronic Engine Controls.

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	Refer to the Description, Possible Causes and Diagnostic Aids for the DTC.		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P0630 - VIN NOT PROGRAMMED OR INCOMPATIBLE - ECM/PCM - DTC CHART

P0630 - VIN NOT PROGRAMMED OR INCOMPATIBLE - ECM/PCM - DTC CHART

Description: This DTC sets when the PCM detects various VID data that is out of a specified