

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test DL .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P1022 - CYLINDER HEAD TEMPERATURE SENSOR 2 CIRCUIT LOW - DTC CHART

P1022 - CYLINDER HEAD TEMPERATURE SENSOR 2 CIRCUIT LOW - DTC CHART

Description: This DTC sets when a CHT2 circuit concern is present.			
Possible Causes: • CHT2 circuit short to ground • Damaged CHT2 sensor • Incorrect CHT2 harness connection			
Diagnostic Aids:			
Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test DL .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P1023 - CYLINDER HEAD TEMPERATURE SENSOR 2 CIRCUIT HIGH - DTC CHART

P1023 - CYLINDER HEAD TEMPERATURE SENSOR 2 CIRCUIT HIGH - DTC CHART

Description: This DTC sets when a CHT2 circuit concern is present.			
Possible Causes: • CHT2 circuit open • CHT circuit short to voltage • Damaged CHT2 sensor • Incorrect CHT2 harness connection			
Diagnostic Aids:			
Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test DL .		