

All	GO to Pinpoint Test DZ .
-----	--------------------------

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P2251 - O2 SENSOR NEGATIVE CURRENT CONTROL CIRCUIT OPEN - BANK 1, SENSOR 1 - DTC CHART

P2251 - O2 SENSOR NEGATIVE CURRENT CONTROL CIRCUIT OPEN - BANK 1, SENSOR 1 - DTC CHART

Description: This DTC sets when a concern is detected with the circuit used to determine the oxygen content in the exhaust gas.			
Possible Causes:			
• UO2SGREF11 circuit open • Damaged universal heated oxygen sensor bank 1, sensor 1 (HO2S11)			
Diagnostic Aids:			
Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test DZ .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P2254 - O2 SENSOR NEGATIVE CURRENT CONTROL CIRCUIT OPEN - BANK 2, SENSOR 1 - DTC CHART

P2254 - O2 SENSOR NEGATIVE CURRENT CONTROL CIRCUIT OPEN - BANK 2, SENSOR 1 - DTC CHART

Description: This DTC sets when a concern is detected with the circuit used to determine the oxygen content in the exhaust gas.			
Possible Causes:			
• UO2SGREF21 circuit open • Damaged universal heated oxygen sensor bank 2, sensor 1 (HO2S21)			
Diagnostic Aids:			
Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test DZ .		