

- Damaged ignition coil
- Damaged ignition coil wiring harness

Diagnostic Aids:

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test JF .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P2309 - IGNITION COIL D PRIMARY CONTROL CIRCUIT LOW - DTC CHART

P2309 - IGNITION COIL D PRIMARY CONTROL CIRCUIT LOW - DTC CHART

Description: This DTC sets when there is a short to ground in the COP4 circuit.

Possible Causes:

- COP4 circuit short to ground
- Damaged ignition coil
- Damaged ignition coil wiring harness

Diagnostic Aids:

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
All	GO to Pinpoint Test JF .		

DIAGNOSTIC TROUBLE CODE (DTC) CHARTS AND DESCRIPTIONS > P2310 - IGNITION COIL D PRIMARY CONTROL CIRCUIT HIGH - DTC CHART

P2310 - IGNITION COIL D PRIMARY CONTROL CIRCUIT HIGH - DTC CHART

Description: This DTC sets when there is a short to voltage in the COP4 circuit.

Possible Causes:

- COP4 circuit short to voltage
- Damaged ignition coil
- Damaged ignition coil wiring harness

Diagnostic Aids:

Application	Key On Engine Off	Key On Engine Running	Continuous Memory
-------------	-------------------	-----------------------	-------------------