


Removal and Installation

Removal

NOTE: Removal steps in this procedure may contain installation details.

1. Refer to: [Wheel Bearing and Wheel Hub - Vehicles With: Rear Disc Brakes](#) (204-02 Rear Suspension, Removal and Installation).
2. Torque: 133 Nm



Installation

1. To install, reverse the removal procedure.